



Users

User is a system object defined by its specific name (login) and password. Users can login to FleeTrak Monitor and control their units with the help of different tools and features. Different users can have different access to units and different set of allowed activities. They can create their own geofences, report templates, etc. non-visible to other users.

How to Manage Users

To work with users, open the *Users* panel in the work area on the left of the window. Here you can create, view, copy, edit, and delete users.

Users ▾			
New	<input type="text"/>		
Duremar			
lambada			
mama			
nana			
octobrian			
papa1			
Tartilla			

or Edit or view user's properties (depending on your access). User properties dialog can contain up to five tabs which were described above:

Create a copy of this user.

Delete user from the system. If the button is dimmed, it means you don't have access rights to delete it.



FleeTrak™



Application of Users

If you have access to several users, it affects system as a whole. You can create objects under a selected user or within their account.

Also, the information of a certain object (driver, geofence, unit, etc.) that belongs to a certain resources or account is displayed in object's tooltip or properties dialog. Besides, in all panels containing filters, there is an additional filter by user/account (in the form of a dropdown list).

Actions of users in the system are logged. For instance, you can view user's (operator's) chat with driver, learn which commands were sent to units by this user, what alterations this user made to some object properties, what objects created, etc. This functionality is available mainly through reports.